

FITTING INSTRUCTIONS FOR URFIC'S EASY LATCH AND DEAD BOLT

The Urfic Easy Latch/Dead Bolt are quick and easy to install. Fitting is approximately three times faster than a standard latch, with minimal carpentry skills required.

Urfic's Easy Latch/Dead Bolt are supplied with both round and square strike plates to suit either new frames or to provide a retrofit solution and are offered with a 1 year guarantee.

HOW TO FIT LATCH OR DEAD BOLT

- ♦ Mark required height on the door and frame
- ♦ Use a set square to mark a horizontal line on leading door edge
- ♦ Transfer height line to edge of door
- ♦ Transfer height line to edge of frame (or as first point)
- ♦ Mark vertical centre line of the door to create an intersection (cross)
- ♦ Mark vertical centre line on the frame (or as first point)
- ♦ Use a 26mm flat head drill bit
- ♦ Mark drill with sticking tape at depth required
- ♦ Keep drill straight and at 90 degrees - mortice out hole
- ♦ Remove any debris
- ♦ Mark position of the spindle and bolt through fixing holes for door furniture
- ♦ Keeping drill straight and at 90 degrees - mortice out hole
- ♦ Remove any debris
- ♦ Check that latch direction is correct (curve of latch head should face the frame)
- ♦ Insert latch into mortice by pushing the round plate against the timber
- ♦ Tap the round plate on either side of latch head until installed (check flush with door edge)
- ♦ Fit door handle as manufacturers instructions

HOW TO FIT STRIKE PLATE (NEW DOOR)

- ♦ With a 32mm bit drill a hole 17mm deep at point of intersection (marked x)
- ♦ Check hole depth - do not drill more than 17mm
- ♦ Secure with fixings provided
- ♦ Position strike plate over the cup
- ♦ Secure the strike plate with fixings supplied
- ♦ Check strike plate is flush with frame

HOW TO FIT STRIKE PLATE (EXISTING DOOR)

- ♦ Remove existing product
- ♦ Insert plastic rectangular casing
- ♦ Adjust to position/reshape woodwork
- ♦ Position fixing plate
- ♦ Secure with fixings provided